



APX®
Center Filler Panel

Step 1. Align filler panels with front surface of the swing frame and fasten them to the frame with M6-1x16 hex head screws and M6-1 hex nuts, as shown. Torque fasteners to 4.3 Nm (38 in-lbs).

Step 2. Install handle with trim washers and M5-.8x16 flat head screws. Torque fasteners to 2.5 Nm (22 in-lbs).

