


# DISCONNECT OPERATOR ADAPTERS FOR PREFERRED CUTOUTS

An operator adapter is required to install a disconnect in Bulletin A21S4, A28S4 and WS2D HOFFMAN enclosures that have a preferred cutout. Operator adapters include components needed to interlock the master door with the disconnect operating mechanism. Panel drilling and installation instructions are furnished with each operator adapter. Each brand and type of disconnect requires a different operator adapter. Be sure to select the proper operator adapter and enclosure for the disconnect that you have selected.



## FEATURES & BENEFITS

Required for disconnect install on products in Bulletins A21S4, A28S4, and WS2D

## SPECIFICATIONS

**Material** Mild Steel

**Color** Gray

**Color Code** ANSI 61

**Finish** Powder Coated

Table 1/1

Catalog Number	Brand and Type of Operator	Thickness
APCABVA	Allen-Bradley 1494V variable-depth; Allen-Bradley 140U, 140G and 1494C cable-operated mechanisms	1.9 mm
APCCHVA	Eaton Cutler-Hammer C361, C371 and C371 Flex Shaft	1.9 mm
APCGETDA	General Electric STDA	1.9 mm
APCITE	Siemens I-T-E Max-Flex	1.9 mm

Catalog Number	Brand and Type of Operator	Thickness
APCSDA	Schneider Square D® Class 9422 variable-depth and cable mechanisms	1.9 mm

2100 Hoffman Way  
Anoka, MN 55303-1745 | USA  
763.421.2240



Our powerful portfolio of brands:  
[nVent.com](https://www.nvent.com) **CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER**

© 2022 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners.  
nVent reserves the right to change specifications without notice.